




The following operation must be completed before the carrier is mounted to the vehicle roof bars. The carrier must be adjusted to suit the particular cycle to be carried.

Position the carrier on the floor and place the cycle onto the carrier. Raise the clamping arm up to the cycle frame.




To adjust the position of the base plate, loosen the four M6 nuts that are situated either side of the longitudinal bar. Offer the clamping arm to the frame of your cycle by sliding the base unit along the longitudinal bar.

Once in the correct position, tighten the nuts to 7Nm and fit the carrier to the vehicle.




Secure the front of the carrier by releasing the quick release handles. Rotate the handles anti-clockwise so the L-Shaped Clamps can be freely attached around the roofbar. Take care to ensure the clamps are located in the slots. Close the quick

release handles to clamp the carrier to the roofbar. The tension can be set by turning the handles clockwise, checking that the quick release handles will close on each full rotation.




Secure the carrier to the other roof bar by unlocking the quick release handle. Rotate the quick release handle anti-clockwise so that the swing arm can be freely rotated out of the way.




Slide the bracket to the point at which the carrier crosses the roof bar and rotate the arm around underside of the roof bar. Fit the head of the coach bolt into the notch of the swing arm. Push the coach bolt as far as possible into the notch


and close the handle to clamp the carrier to the roof bar. The tension may be set by turning the handle clockwise, checking that the quick release handle will close on each full rotation.




To make fitting of the cycle easier, secure the front wheel using the 52cm strap. **Warning: Ensure the strap is inserted through the cam buckle in the correct direction.**




Release the jaws of the clamping assembly by unlocking, lifting the handle and rotating it anti-clockwise. The clamp may be unscrewed and reversed to provide either left or right access.



Lift your cycle onto the carrier ensuring both tyres are positioned centrally on the tyre locators.




Raise the clamping assembly and secure the frame. Close the handle to secure the clamp to the frame. Check that it is secure. If not release by lifting the handle and rotate it clockwise to tighten. Once secure lock handle.



Release the tyre locator handles and feed the straps through each wheel. Locate the metal loop onto the furthest achievable clip. Push the handle down to lock the wheel to

the tyre locator. If the strap is not holding the wheel firmly in position, repeat the above operation making sure to move the metal loop to the next available clip.



When driving without a cycle fitted, the clamping arm should be secured to the longitudinal bar using the 52cm straps and the tyre locators fixed in position. Carry out the same operation to secure the tyre locators as when clamping the cycle.

Important Instructions


- Retain these instructions for future reference, ensure that any other users of the cycle carrier are familiar with their contents.
- Please read the fitting instructions carefully.
- Make sure that all parts are included in the package.
- Prior to fitting ensure that the vehicle roof bars are free from dirt and grime.
- IMPORTANT! Carrier clamping mechanisms must always be re-tightened after cycle has been mounted to the carrier.
- After driving for a few miles STOP and check that all clamping mechanisms are secured and tight. This must be repeated at suitable intervals depending on the nature of the road.
- The maximum permissible roof loads must not be exceeded (see vehicle handbook for details of the maximum roof loads). The roof load will comprise of the weight of the load bars, the carrier plus additional racks and the cycle load. Do not exceed a maximum load of 15kg per cycle carrier (1 adult cycle).
- When using the carrier the driving handling characteristics of your vehicle will change. Driving techniques should be altered to allow for this. Reduce speeds (max 70mph) and allow longer braking distances.
- When fitted, the roof bars will affect your fuel economy, therefore please remove when not in use.
- Take care not to drive in low places such as garages or multistorey car parks.
- When positioning cycles on the carrier ensure that they do not project beyond the profile of the vehicle and that no part of the cycle can touch the paintwork.
- The use of cycle carriers may be restricted in certain countries outside the UK. Always check with the relevant national authorities prior to commencing your journey.
- Do not put the car through an automatic car wash with the load carrier mounted.
- Ensure this carrier is maintained and kept in good working order.



Deluxe Roof Mount Carrier Fitting Instructions

Please follow instructions carefully to ensure the safety of yourself and other road users. The initial assembly and fitting of this carrier will take approximately 15 minutes. Before you begin:

- Make sure all parts are included in the package.



Halfords Ltd. Washford Redditch B98 0DE
Made in the UK